TGA807E(e).fm Page 1 Monday, April 16, 2007 6:17 PM

Panasonic

Installation Manual

Additional Digital Cordless Handset

Model No. **KX-TGA807E**



This unit is an additional handset for use with the following Panasonic Digital Cordless Phones:
KX-TG8070/KX-TG8090
You must register this handset with your base unit before it can be used. This installation manual describes only the steps needed to register and begin using the handset. Please read the base unit's operating instructions for further details.

Charge the batteries for about 8 hours before initial use.

Please read this installation manual before using the unit and save it for future reference.

Thank you for purchasing a new Panasonic digital cordless phone.

Additional/replacement accessories

Model No.	Description
P03P*1	2 rechargeable nickel metal hydride (Ni-MH) batteries, AAA (R03) size

*1 Replacement batteries may have a different capacity from that of the supplied batteries.

Note:
- This equipment is designed for use in the UK and Republic of Ireland.
- In the event of problems, you should contact your equipment supplier in the first instance.

Supplied accessories

Charger
Part No. PQWETGA807E

Rechargeable batteries AAA (R03) size Part No. HHR-4EPT	Handset cover*1 Part No. PQYNTG8070ER	Belt clip Part No. 300748200200

*1 The handset cover comes attached to the handset.

Important information

General
- Use only the AC adaptor supplied with this product.
- Do not connect the AC adaptor to any AC outlet other than a standard 220-240 V AC outlet.
- This product is unable to make calls when:
  - the portable handset battery(ies) need recharging or have failed.
  - there is a power failure.

- the key lock feature is turned on.

• Do not open the charger or handset other than to replace the battery(ies).
• This product should not be used near emergency/intensive care medical equipment and should not be used by people with pacemakers.
• Care should be taken that objects do not fall onto, and liquids are not spilled into, the product. Do not subject this product to excessive smoke, dust, mechanical vibration or shock.

Environment

• Do not use this product near water.
• This product should be kept away from heat sources such as radiators, cookers, etc. It should also not be placed in rooms where the temperature is less than 5 °C or greater than 40 °C.
• The AC adaptor is used as the main disconnect device. Ensure that the AC outlet is installed near the product and is easily accessible.

Warning:

• To prevent the risk of electrical shock, do not expose this product to rain or any other type of moisture.
• Unplug this product from power outlets if it emits smoke, an abnormal smell, or makes unusual noise. These conditions can cause fire or electric shock. Confirm that smoke has stopped emitting and contact an authorised service centre.
• Do not place or use this product near automatically controlled devices such as automatic doors and fire alarms. Radio waves emitted from this product may cause such devices to malfunction resulting in an accident.
• Regularly remove any dust, etc. from the AC adaptor/power plug by pulling it from the power outlet, then wiping with a dry cloth. Accumulated dust may cause an insulation defect from moisture, etc. resulting in a fire.
• Do not damage the power cord/plug. This may cause a short circuit, electric shock, and/or fire.
• Do not touch the plug with wet hands.

Battery caution

• We recommend using the battery(ies) noted on page 2. **Use only rechargeable battery(ies)**.
• Do not mix old and new batteries.
• Do not dispose of the battery(ies) in a fire, as they may explode. Check with local waste management codes for special disposal instructions.
• Do not open or mutilate the battery(ies). Released electrolyte from the battery(ies) is corrosive and may cause burns or injury to the eyes or skin. The electrolyte may be toxic if swallowed.

- Exercise care when handling the battery(ies). Do not allow conductive materials such as rings, bracelets or keys to touch the battery(ies), otherwise a short circuit may cause the battery(ies) and/or the conductive material to overheat and cause burns.
- Charge the battery(ies) provided with or identified for use with this product only in accordance with the instructions and limitations specified in this manual.
- Only use a compatible base unit (or charger) to charge the battery(ies). Do not tamper with the base unit (or charger). Failure to follow these instructions may cause the battery(ies) to swell or explode.

Notice for product disposal, transfer, or return

- This product can store your private/confidential information. To protect your privacy/confidentiality, we recommend that you erase the information such as phonebook or caller list entries from the memory before you dispose, transfer or return the product.

Information on Disposal for Users of Waste Electrical & Electronic Equipment (private households)

This symbol on the products and/or accompanying documents means that used electrical and electronic products should not be mixed with general household waste.
For proper treatment, recovery and recycling, please take these products to designated collection points, where they will be accepted on a free of charge basis. Alternatively, in some countries you may be able to return your products to your local retailer upon the purchase of an equivalent new product.
Disposing of this product correctly will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling. Please contact your local authority for further details of your nearest designated collection point. Penalties may be applicable for incorrect disposal of this waste, in accordance with national legislation.

For business users in the European Union

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

Information on Disposal in other Countries outside the European Union

This symbol is only valid in the European Union.
If you wish to discard this product, please contact your local authorities or dealer and ask for the correct method of disposal.

Connection

The AC adaptor must remain connected at all times. (It is normal for the adaptor to feel warm during use.)

Location

- For maximum distance and noise-free operation, place your base unit:
  - away from electrical appliances such as TVs, radios, personal computers or other phones.
  - in a convenient, high and central location.

Battery installation

Important:

- Use only the supplied rechargeable batteries noted on page 2, 3.
- USE ONLY rechargeable Ni-MH batteries AAA (R03) size.
- Do NOT use Alkaline/Manganese/Ni-Cd batteries.
- Ensure correct polarities (⊕, ⊖) when installing the batteries.
- Wipe the battery ends (⊕, ⊖) with a dry cloth.
- When installing the batteries, avoid touching the battery ends (⊕, ⊖) or the unit contacts.

1 Press the notch on the handset cover firmly and slide it in the direction of the arrow.



2 Insert the batteries negative (⊖) end first. Close the handset cover.



Battery charge

Place the handset on the charger for about 8 hours before initial use.

Note:

- The handset display may show **"Register!"** when the handset is placed on the charger if it is not registered to a base unit.
- If you fully charged the batteries, but the operating time seems to be short, wipe the battery ends (⊕, ⊖) and the unit contacts with a dry cloth.

Wall-mounting



Note:

- Make sure the screws are securely fastened to the wall.

Registering the handset to the KX-TG8070/KX-TG8090 base unit

Make sure that the batteries are installed correctly.

1 Press and hold **[•))]** on the base unit for about 5 seconds until a beep is heard.
- If all registered handsets start ringing, press **[•))]** to stop, then repeat this step.
- After a beep is heard, the rest of this procedure must be completed within 1 minute.

2 **[MENU]** (right soft key) → ✎ → **[OK]**
3 **[▲]/[▼]**: **"Registration"** → **[OK]**
4 **[▲]/[▼]**: **"Register Handset"** → **[OK]**
5 **[▲]/[▼]**: Select a base unit number. → **[OK]**
- This number is used by the handset as a reference only.
- The registered base unit is indicated by "∗".

6 **"Enter PIN"** is displayed. Enter the base unit PIN (default: **"0000"**). → **[OK]**
- If you forget your PIN, consult your nearest Panasonic service centre.
- When the handset has been registered successfully, Ψ will stop flashing. If the key tone is turned on, a confirmation tone will be heard.

Note:
- The KX-TG8070 does not feature an answering system.
- Answering system features are available only when this handset is registered to the KX-TG8090.

Declaration of Conformity:
- Panasonic Communications Co., Ltd. declares that this equipment is in compliance with the essential requirements and other relevant provisions of Radio & Telecommunications Terminal Equipment (R&TTE) Directive 1999/5/EC.
  Declarations of Conformity for the relevant Panasonic products described in this manual are available for download by visiting:
  http://www.doc.panasonic.de

Contact:
Panasonic Services Europe
a Division of Panasonic Marketing Europe GmbH
Panasonic Testing Centre
Winsbergring 15, 22525 Hamburg, Germany

TGA807E(e).fm Page 8 Monday, April 16, 2007 6:17 PM

Sales and support information
Customer Care Centre
- For customers within the UK: 0844 844 3898
- For customers within the Republic of Ireland: 01289 8333
- Visit our website for product information: **www.panasonic.co.uk**
- E-mail: **customer.care@panasonic.co.uk**

Direct Sales at Panasonic UK
- Order accessory and consumable items for your product with ease and confidence by phoning our Customer Care Centre Monday - Thursday 9:00am - 5:30pm, Friday 9:30am - 5:30pm (Excluding public holidays).
- Or go on line through our Internet Accessory ordering application at **www.panasonic.co.uk**
- Most major credit and debit cards accepted.
- All enquiries transactions and distribution facilities are provided directly by Panasonic UK Ltd.
- It couldn't be simpler!
- Also available through our Internet is direct shopping for a wide range of finished products, take a browse on our website for further details.

CE0682

1999/5/EC

Sales Department:
Panasonic Business Systems U.K.
Panasonic House, Willoughby Road, Bracknell, Berkshire, RG12 8FP

Panasonic Communications Co., Ltd.
1-62, 4-chome, Minoshima, Hakata-ku, Fukuoka 812-8531, Japan

Copyright:
This material is copyrighted by Panasonic Communications Co., Ltd., and may be reproduced for internal use only. All other reproduction, in whole or in part, is prohibited without the written consent of Panasonic Communications Co., Ltd.

© 2007 Panasonic Communications Co., Ltd. All Rights Reserved.

PQQX15914ZA DC0407DM0